

## INSTALLATION INSTRUCTIONS FOR WOODEN OR STEEL THRESHOLD

**WARNING: PROTECT THE WOODEN THRESHOLD FROM MOISTURE AND WETTING!**

The product does not contain hazardous substances as specified in Regulation (EC) No. 1907/2006 of the European Parliament and Council of December 18, 2006.

**REQUIRED INSTALLATION TOOLS:** screwdriver or drill, spirit level, hammer, construction adhesive, wood-cutting tools.

### PRODUCT FEATURES

1. The wooden threshold is made of hardwood and surface-treated to protect against moisture.
2. The steel threshold is made of stainless steel sheet.

### INTENDED USE

1. The product is designed to seal the opening in the wall of rooms with a relative humidity not exceeding 50-60%, and at a temperature suitable for human-occupied rooms (i.e., +20°C or higher).
2. Installation is prohibited in areas with consistently high humidity, such as laundries, saunas, swimming pools, basements, and garages.

### BEFORE ASSEMBLY

1. It is recommended to use qualified installation professionals.
2. Work should be carried out in accordance with building standards and health and safety regulations.
3. Installation should begin only after the completion of other renovation and construction work in rooms with a humidity level not exceeding 50-60%.

### ASSEMBLY

1. Open the packaging without damaging the manufacturer's labels.
2. Check the product against the order specifications.
3. Check the preparation of the substrate, which must be insulated with thermal and waterproof insulation, flat, stable, dry, and free from contaminants.
4. Check the dimensions (length and width) of the threshold against the substrate.
5. Paint the wooden threshold in the desired color using high-wear-resistant wood paint.
6. Apply construction adhesive suitable for bonding concrete/wood to the threshold, and immediately position it in place (for wooden thresholds), then insert the door frame.
7. Use wood screws (3.5x40 mm) to secure the threshold to the door frame. Optionally, apply construction adhesive suitable for bonding concrete/metal and secure the door frame in place.  
**Note:** Before securing the screws, drill holes with a 3 mm drill to a depth of 30-40 mm.
8. Ensure the door fits evenly with the threshold seal.
9. Fill any gaps between the threshold and the substrate, or between the threshold and door frame with neutral silicone (not sanitary!).

### CECHY PRODUKTU

1. Remove dirt using a damp cloth.
2. The manufacturer is not responsible for any side effects caused by cleaning agents. Before use, it is recommended to test the agent on a small area by applying it with a cloth.
3. Any necessary adjustments due to reduced functionality over time should be performed immediately by qualified installers (this service is outside the warranty coverage of the door manufacturer and installation company).
4. Protect from moisture and water exposure.

**Note:** The surface of the thresholds wears with the intensity of use.